



Inside Relay Box
 ANET39A0 : Power for Relay PCB
 ANET41A0 : Wires for Solenoid Valves
 ANET43A0 ; Wires for transformer
 ANET82A0 : Signals for relays
 ANET85A0 : Wires for capacitor
 AGER31A0 : Relay PCB CLESTA2-RY-2005